



LOCATION GUIDE FOR THE INSTALLATION OF OZONISERS.



DO NOT INSTALL

- Over washbasins.
- Over urinals.
- Near windows or other ventilation.
- Touching ceilings. (Must be 30cm- 12ins below ceiling height.)
- Below pipework.



DO INSTALL

- Away from washbasins.
- Away from urinals.
- Away from windows and other ventilation.
- At least 30cm (12 in below the ceiling.)
- Above pipework. (This avoids condensation dripping on to unit.)
- Out of reach from the public.